



Custom Dynamics® Indian® Black Saddlebag Trim Installation Instructions

We thank you for purchasing the Custom Dynamics® Indian® Black Saddlebag Trim. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers:

CD-IND-SB-T-B

Package Contents:

- Black Trim (2)



Fitment: 2015-2018 Indian® Chieftain, Chieftain Dark Horse, 2018-2020 Chieftain Classic, 2018 Chieftain Limited, 2015-2022 Roadmaster, 2018-2021 Roadmaster Elite, 2016-2022 Springfield & 2018-2019 Springfield Dark Horse.

Installation:

1. Remove the chrome trim strip from the back of both saddle bags.
2. Clean the trim strip area with denatured alcohol, allow to dry.
3. Install the provided replacement chrome trim strips on the back of both saddle bags.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of vehicle.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST